

# Mounting Instruction

## IP65 LED II

**Bemærk:**

- Servicing af LED enhed og LED driver, må kun udføres af en kvalificeret person.
- Sikre dig at armaturet er i spændingsløs tilstand, før LED enhed åbnes eller ved udførsel af service.
- "ESD følsom" undgå alt unødvendig berøring af LED paneler og LED drivere.
- Optiske linser eller anden form for optik, skal altid være monteret når armaturet er i drift.
- Armaturer med DALI driver, skal være tilsluttet en god og aktiv jordforbindelse.

**Attention:**

- Servicing of LED geartray and LED driver, may only be performed by an qualified person.
- Always power of luminaire before opening LED geartray or performing service.
- "ESD sensitive" avoid unnecessary touching LED boards and LED drivers.
- Optical lenses and other forms of optics, must always be mounted when luminaire is in operation.
- Luminaire with DALI driver must have an active ground connection.

### Montage/Installing

DK = Til brug indendørs eller udendørs overdækket.  
 GB = For use indoor or outdoor covered.

